

HC36 Natural Ventilation Controller



- Can control up to four zones of inlets.
- Monitors temperature in four zones from four remote sensors.
- Each zone can be set independently or from a master zone.
- Each zone can be configured to control:
 - Inlets without feedback potentiometer.
 - Inlets with feedback potentiometer.
 - Heating.
- Large display shows temperature in the selected zone.
- Min. and max. memory recall for each of the four zones.
- Each inlet zone has independent min. and max. opening positions.
- Indicator lamps show the status of the relay outputs.
- Simple feedback potentiometer calibration procedure.
- Eight relay outputs, two per zone (open & close).
- Supplied with:
 - 4 x Temperature sensors.
- Available as:
 - Panel Mount.